

EZ AIM® 23"X35" DECK OF CARDS CORRUGATED TARGET & BACKER - ALLEN CO INC EZ AIM 23"X35" DECK OF CARDS CORRUGATED TARGET & BACKER

ALLEN CO INC. EZ AIM® 23"X35" DECK OF CARDS CORRUGATED TARGET & BACKER Elevate your shooting experience with the EZ Aim® Corrugated Deck of Cards Target & Backer, designed to inject more fun into your target practice. Crafted from corrugated stock, this target serves as a dependable backerboard and features a full deck of cards printed on the target. Unlock a world of shooting entertainment with this unique target, as it allows you to engage in a variety of card games using your firearm. Whether it's a round of target poker or a challenging game of "Hit or Stand," this target offers endless possibilities to elevate your range experience. Provided in the pack is 1-shooting target, measuring 23 x 35-inches, ensuring exceptional visibility and precision during your shooting sessions. Elevate your shooting experience with the EZ Aim® Corrugated Deck of Cards Target & Backer, where durability meets entertainment, and every shot deals a winning hand. **FEATURES**
DURABLE SHOOTING TARGET & BACKER: Crafted from a sturdy heavy-duty cardboard sheet for lasting resilience. **CARD GAME SHOOTING TARGET:** Features a complete deck of cards printed directly on the target for added entertainment. **PRECISION PRACTICE:** Designed with 52- cards to provide a challenge & accuracy to your training sessions. **SHOOTING TARGETS:** Each target measures 23-inches wide x 35-inches tall, providing ample space for precise targeting and enjoyment. **SPECS** Material: Paper Targets Size: 23 Inch x 35 Inch Weight: 0.2 lb

NO IMAGE
AVAILABLE

Attributes

- Name: ALLEN CO INC EZ AIM 23"X35" DECK OF CARDS CORRUGATED TARGET & BACKER
- Manufacturer: ALLEN CO INC
- Product no.: 430119962
- Mfr. No.: 15733
- Style: Bullseye
- Target Size/Type: 23 x 35
- Type: Papers
- Delivery weight: 0.091kg
- Shipping height: 584mm
- Shipping width: 889mm
- Shipping length: 4mm
- UPC: 026509075905

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer](#)
- [Italiano: Guida alle Istruzioni di Sicurezza per il Bersaglio EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer](#)
- [Norsk: Bruksanvisning for sikkerhet EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer](#)

Safety Instruction Guide for EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer

Introduction

Thank you for choosing the EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer. This product is designed to enhance your shooting experience while ensuring safety during use. Please read this safety instruction guide carefully to understand how to use the target safely and effectively.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Ensure that you are in a safe shooting environment with a proper backstop.
- Use the target only in designated shooting areas.
- Keep the target out of reach of children and unauthorized users.
- Inspect the target for any damage before use. Do not use if damaged.
- Follow all local laws and regulations regarding firearm use and target shooting.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use only in areas where shooting is permitted and safe.
- Ensure that all participants are wearing appropriate eye and ear protection.
- Maintain a safe distance from the target when shooting.
- Do not shoot at the target if it is not securely mounted or positioned.
- Be aware of your surroundings and ensure that no one is in the line of fire.
- Avoid using the target in windy conditions, which may affect stability.
- Do not modify the target or use it for purposes other than intended.

Instructions for Installation and Usage

1. Installation

- Select a stable and flat surface for mounting the target.
- Ensure that the target is positioned at a safe distance from the shooter and any bystanders.
- Secure the target using appropriate methods (e.g., stakes, clamps) to prevent it from falling over.
- Check that the target is level and stable before use.

2. Usage

- Before shooting, ensure that the area is clear of people and obstacles.
- Position yourself at a safe distance from the target, as recommended for your shooting discipline.
- Aim carefully and take your shot, ensuring that the firearm is pointed in a safe direction.
- After shooting, check the target for any damage or wear.
- Dispose of any damaged targets responsibly.

Disposal Instructions

- Dispose of the target in accordance with local waste management regulations.
- If the target is damaged, do not attempt to repair it. Instead, dispose of it properly.
- Recycle the cardboard material if possible, following local recycling guidelines.

Contact Information for Further Support

For any questions or concerns regarding the EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer, please refer to the product packaging or contact the manufacturer directly through the provided channels.

By following these safety instructions, you can enjoy a fun and safe shooting experience with your EZ AIM® target. Always prioritize safety and adhere to the guidelines to ensure a positive experience.

Guida alle Istruzioni di Sicurezza per il Bersaglio EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer

Introduzione

Grazie per aver scelto il bersaglio EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer di ALLEN CO INC. Questa guida fornisce informazioni importanti sulla sicurezza e sull'uso corretto del prodotto, in conformità con le normative europee sulla sicurezza dei prodotti. Leggi attentamente queste istruzioni per garantire un utilizzo sicuro e divertente del bersaglio.

Linee Guida Generali di Sicurezza

- Assicurati che il bersaglio sia utilizzato solo in ambienti sicuri e appropriati, lontano da persone e animali.
- Controlla sempre il bersaglio prima dell'uso per verificare eventuali danni o usura.
- Non utilizzare il bersaglio se presenta segni di danneggiamento o se non è stabile.
- Conserva il bersaglio in un luogo asciutto e lontano da fonti di umidità per evitare deterioramenti.
- Segnala eventuali prodotti non sicuri o incidenti alle autorità competenti.

Precauzioni di Sicurezza Specifiche per l'Uso

- Utilizza il bersaglio solo con proiettili o frecce adatte e specificamente progettati per il tiro su bersagli in cartone.
- Non colpire il bersaglio con oggetti diversi dai proiettili o dalle frecce progettate per l'uso.
- Assicurati che il bersaglio sia posizionato su una superficie piana e stabile.
- Mantieni una distanza di sicurezza durante l'uso e assicurati che nessuno si trovi nella traiettoria di tiro.
- Non utilizzare il bersaglio in condizioni meteorologiche avverse (ad esempio, pioggia o vento forte).

Istruzioni per l'Installazione e l'Uso

1. Posizionamento del Bersaglio

- Scegli un'area aperta e sicura per posizionare il bersaglio.
- Assicurati che il bersaglio sia fissato saldamente e non possa cadere o muoversi durante l'uso.

2. Preparazione al Tiro

- Verifica che l'area intorno al bersaglio sia libera da ostacoli e persone.
- Controlla che il bersaglio non sia danneggiato e che tutte le parti siano intatte.

3. Utilizzo del Bersaglio

- Inizia la sessione di tiro mantenendo sempre l'attenzione sulla sicurezza.
- Colpisci il bersaglio solo con proiettili o frecce appropriati.
- Dopo ogni colpo, verifica il bersaglio per eventuali danni.

Istruzioni per lo Smaltimento

- Quando il bersaglio non è più utilizzabile, smaltiscilo in modo responsabile.
- Verifica le normative locali per lo smaltimento dei materiali di cartone.
- Se possibile, ricicla il bersaglio per ridurre l'impatto ambientale.

Informazioni di Contatto per Ulteriore Supporto

Per domande o ulteriori informazioni sulla sicurezza del prodotto, contatta il tuo rivenditore o il produttore. Assicurati di avere il numero di modello e le informazioni di acquisto a portata di mano per facilitare l'assistenza.

Ricorda che la tua sicurezza è la priorità. Segui attentamente queste istruzioni e goditi il tuo tempo di tiro con il bersaglio EZ AIM®!

Bruksanvisning for sikkerhet EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer

Introduksjon

Velkommen til din nye EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer. Dette produktet er designet for å forbedre din skyteopplevelse ved å kombinere holdbarhet med underholdning. For å sikre trygg og effektiv bruk, vennligst les og følg disse sikkerhetsinstruksjonene nøye.

Generelle sikkerhetsretningslinjer

- Sørg for at produktet brukes i et sikkert miljø, borte fra barn og sårbare grupper.
- Les alltid bruksanvisningen før bruk.
- Kontroller at målet er i god stand før hver bruk og bytt det ut ved tegn på slitasje eller skade.
- Bruk alltid passende sikkerhetsutstyr, inkludert øye og hørselsvern, når du bruker skytevåpen.
- Oppbevar alltid skytevåpen og tilbehør utilgjengelig for barn.

Spesifikke sikkerhetstiltak for bruk

- Unngå å bruke målet i dårlig vær eller under ugunstige forhold, som sterk vind eller regn.
- Sørg for at det er tilstrekkelig plass rundt målet for å unngå utilsiktede skudd.
- Bruk målet kun med godkjente skytevåpen og ammunisjon.
- Hold alltid våpenet rettet bort fra personer og dyr.
- Følg alltid produsentens retningslinjer for bruk av skytevåpen.

Instruksjoner for installasjon og bruk

- Plasser målet på en stabil overflate, som en skytebane eller et annet egnet sted.
- Sørg for at målet er sikret og ikke kan velte under bruk.
- Når du er klar til å begynne, ta plass i en trygg avstand fra målet.
- Skyte mot målet med forsiktighet og presisjon.
- Etter bruk, inspiser målet for skader og reparer eller bytt det ut om nødvendig.

Avfallsinstruksjoner

- Når målet er utslitt eller skadet, må det kastes på en ansvarlig måte.
- Undersøk lokale retningslinjer for avfallshåndtering for resirkulering av papirmaterialer.
- Unngå å kaste målet i naturen eller på offentlige steder.

Kontaktinformasjon for videre støtte

For spørsmål angående sikkerhet eller bruk av produktet, vennligst kontakt produsenten eller forhandleren der produktet ble kjøpt.

Vennligst vær oppmerksom på at det er viktig å rapportere eventuelle usikre produkter eller ulykker til relevante myndigheter. Sjekk også for tilbakekallingsoppdateringer på EU's Safety Gateplattform for å holde deg informert om sikkerheten til produkter.

Takk for at du valgte EZ AIM® 23"X35" Deck of Cards Corrugated Target & Backer. Vi håper du får en trygg og underholdende skyteopplevelse!